



The First Door to Your Day

**Basic Manufacturer Maintenance Recommendations to
Maximize the Life and Benefit of Your
Hydrophobic Treated Surface:**

GT Shower Doors Ltd. recommends using only clean water and a nylon puff every 2-4 weeks. If you would like to buy cleaning products the following cleaners may be used:

- Ammonia Free Windex
- Sprayway
- Simple Green
- Diluted Vinegar with Water (1:3)

After Each Use: For best results, rinse or spray the surface with clean water and towel dry the few remaining drops. Or just thoroughly towel dry the door. You may also use a squeegee.

Once a Month: Wet the surface and use a nylon body puff to go over the wet surface, rubbing in a circular motion. You should feel places that are “sticky” going back to slick again. Then rinse or spray the surface with cool, clean water just as you do after each use. Wipe it dry or let the water drain off, and pat dry the few remaining droplets.